


SNEAKY SOAKER 3

0010-9139



See Specification Sheet for product data.



WATER EFFECT

SPLASH



INSTALLATION

ZERO-DEPTH + WADING POOL




PLAYPHASE™

DETACHABLE MOUNTING SYSTEM

PLAY OPPORTUNITIES:

Keep waterplayers on their toes with the Sneaky Soaker 3. Its bell-shaped tipping buckets spill and dump water at random intervals to create bursts of excitement on the play pad.



COGNITIVE



SOCIAL



PHYSICAL

Play is fundamental in childhood development, health and wellbeing. Waterplay products are designed using research that supports cognitive, social and emotional, creative and physical growth. The above icons represent the leading attributes associated with this play feature.

PLAY ZONES:



EXPLORATION



ADVENTURE

CATEGORY: Soakers & Spinners

PRODUCT LINE: Freestanding Play

WATERPLAY
BY **MAKER**

1.800.590.5552 (USA & CAN) | +1 (250) 712.3393 (INTL)
info@waterplay.com | www.waterplay.com

For full product specification details, please refer to the product specification document. Due to our continuing product improvement program, Waterplay™ reserves the right to change the product specifications without notice. All product designs at all times remain the property of Waterplay or are used under license and cannot be used or reproduced without written permission.